Welcome Start Guide

ZTE Quartz



ZTE *Quartz*[®] Start Guide

TCS534395.1

Content

Getting to Know Your Watch 4
Charging the Watch6
Turning your watch ON and OFF 8
Setting Up for the First Time9
Waking Up the Watch 11
Placing a Call12
Sending a Message13
Control Mobile Data15
Connect to a Wi-Fi Network 15
Pairing With Bluetooth Devices 16
Information About Safeguarding
Handsets16
Approved Firmware Versions 18
Emergency Dialing18
Additional Information 20
For Your Safety 22
General Safety 22
Radio Frequency (RF) Energy . 24

FCC Regulations	25
CTIA Requirements	28
Distraction While Walking	30
Product Handling	31
Electrical Safety	40
Radio Frequency Interference	41
Explosive Environments	44
Manufacturer's Warranty	45
LIMITED WARRANTY	48
LEGAL INFORMATION	50

Getting to Know Your Watch



4

- 1. Watch bands
- 2. Touch screen
- 3. Microphone
- 4. Power button
 - Press and hold to power on the watch.
 - When the screen is on, press to access the applications list.
 - When the screen is dimmed, press to wake up the watch.
 - When the screen is on, press and hold to access Speak now.
 - When there is no ongoing phone call, press to return to the clock face from any other interface.
- 5. Barometer
- 6. Charging connector
- 7. Speaker

Charging the Watch

It is recommended to only use the included ZTE charging dock and cable to charge your watch.

1. Connect the charging cable to the micro-USB port on the charging terminal.



 Place watch on the charging dock, making sure is oriented correctly so the watch and charging dock contacts are aligned.





- You can also connect the cable to a USB port on your computer to charge the watch.
- It is normal for the device to become slightly warm during charging.
- Use the ZTE charging dock that came with your device. Use of other chargers may damage the device and void the warranty.



To save battery power, some non-essential applications will be disabled when the battery is low.

Turning your watch ON and OFF

- Press and hold the **Power** button to turn ON the watch.
- From the Clock Screen, press the Power button and select Settings > System > Power



```
- or-
```

Swipe your finger down from the top of the Clock Screen and select ***** > System > Power off > .

Setting Up for the First Time

Before using the watch, you need to set it up when powering it on for the first time.

- 1. Touch the screen to begin.
- 2. Slide on the screen and select the language you want to use.
- Follow the prompts displayed and download Android Wear™ from Google Play Store and install it on your phone. Always download the latest App version.
- 4. Open Android Wear[™] on your phone and select SET IT UP.

💋 NOTES:

- Android Wear[™] App requires a phone running Android 4.3+ or iOS 8.2+. Supported features may vary between platforms.
- Visit g.co/wearcheck on your Android phone or iPhone® to see if it's compatible.

- Your phone automatically scans for and displays the IDs of all available devices in range.
- 5. Select the name of your watch.
- Confirm that the pairing codes are the same between the two devices and Select **Pair**. Scroll down the notification bar from your phone to confirm pairing the devices.



After connection, the phone and watch will automatically check for updates.

- 7. Select or add a Google account to copy to your watch.
- Follow the on screen instructions to complete the setup and touch DONE.



- Make sure your phone is next to your watch.
- Make sure your phone is connected to mobile data or Wi-Fi. You need a data connection to set up your watch for the first time.
- Depending on the network condition, the setup process might take a few minutes.

Waking Up the Watch

After some time of inactivity, the screen of the watch dims to save battery power. You can wake up the watch using the following two methods.

- Touch the screen.
- Press the **Power** button.
- Turn your wrist so your watch face is upright.

Placing a Call

- 1. If the screen is dimmed, touch the screen to wake up the watch.
- From the Clock Screen, press the Power button and select Phone.
- Swipe left or right to switch between different screens. Use one of the following methods to place a call.
 - In the Contacts screen, slide on the screen to touch the contact you want to call

and Select



- In the Recents screen, scroll through the history and select the log you want to call.
- In the dialpad screen, enter a number using the dialpad and select .

Sending a Message

This feature enables you to send messages using your watch.

- 1. If the screen is dimmed, touch the screen to wake up the watch.
- 2. From the Clock Screen, press the **Power** button and select **Messenger**.
- Select between phone and watch.
- Select New message and select recipient displayed in the screen and Select If there is an ongoing conversation with the contact, Select the conversation and then Select S
- Enter the content of the message. You can use text templates, write new text, or send an MMS with doodles.

- Swipe up or down to select a text template from fixed phrases or recently used texts from the list.
- Select to open the text screen. Select the text field to open the onscreen keyboard and enter the text.

You can also Select () to write words with your finger on the screen.

- Select is to open the doodle screen. You can draw an image with your finger.
- Select U to use Speak now to enter your message.



Control Mobile Data

- 1. If the screen is dimmed, touch the screen to wake up the watch.
- From the Clock Screen, press the Power button and select Settings > Connectivity > Cellular.
- Select Cellular to turn on or off the mobile data service of the SIM card.

Connect to a Wi-Fi Network

- 1. If the screen is dimmed, touch the screen to wake up the watch.
- From the Clock Screen, press the Power button and select Settings > Connectivity > Wi-Fi.
- 3. Select Wi-Fi to turn on Wi-Fi.
- 4. Select Add network.
- 5. Select a network name.
- Select Enter on phone to enter the password of the network on the phone and connect to it.

Pairing With Bluetooth Devices

- 1. If the screen is dimmed, touch the screen to wake up the watch.
- From the Clock Screen, press the Power button and select Settings > Connectivity > Bluetooth and turn Bluetooth on.
- Select Available devices to scan for and display the IDs of all available devices in range.
- 4. Select the name of the device.

Information About Safeguarding Handsets

T-Mobile encourages customers to take appropriate measures to secure their handsets and invites them to take advantage of the features available on this handset to help secure it from theft and/or other unauthorized access and use. This handset has a locking function (e.g., user-defined codes or patterns) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts.

For additional information, visit:

www.t-mobile.com/devicesecurity and www.t-mobile.com/Company/PrivacyR esources.aspx

Approved Firmware Versions

This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device it will not function

Emergency Dialing

Although all phones are equipped with 9-1-1 emergency calling, this phone may or may not permit its location to be approximated during a 9-1-1 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits. network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency), Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

Additional Information

Use of some content or features may require qualifying service, or access to Wi-Fi connection.

Wi-Fi: Device will not transition data sessions between Wi-Fi and the cellular network. Devices using wireless connections may be vulnerable to unauthorized attempts to access data and software stored on the device. Plan data allotment applies to use by connected devices sharing Wi-Fi. Use of connected devices subject to T-Mobile Terms and Conditions. Device, screen and accessory images simulated. Coverage not available in some areas. See **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details, **including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling.**

For Your Safety

General Safety

F	Don't use at gas stations.
žķ	Your device may produce a bright or flashing light.
8	Small parts may cause choking.
×	Don't dispose of your device in fire.
E State	Your device can produce a loud sound.
	To prevent possible hearing damage, do not listen at high volume levels for long periods.
C.	Avoid contact with anything magnetic.

J	Avoid extreme temperatures.
R	Keep away from pacemakers and other electronic medical devices.
	Avoid contact with liquids. Keep your device dry.
Ð	Turn off when asked to in hospitals and medical facilities.
) T	Don't take your device apart.
A-	Turn off when told to in aircrafts and airports.
Q I	Only use approved accessories.



Turn off when near explosive materials or liquids.

Radio Frequency (RF) Energy

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

The exposure standard for wireless employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg for 1g SAR and 4.0W/kg for 10g SAR.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: SRQ-ZW10.

For this device, the highest reported body SAR value is 0.95 W/kg and the highest wrist-worn SAR value is 1.90 W/kg.

FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CTIA Requirements

- Do not disassemble or open crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.

- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the watch or battery. If the watch or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

- Improper battery use may result in a fire, explosion or other hazard.
- The watch shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

Distraction While Walking

Full attention must be given to traffic at all times when walking or running in order to reduce the risk of an accident. Please observe relevant provisions on prohibitions or restrictions on the use of mobile phones.

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your device and any consequences of its use.

- Always treat your device and its accessories with care.
- Do not cover or touch the antenna area during phone calls. Doing so may affect signal transmission and consume more battery power.
- Clean the device and its accessories with a soft material such as cleaning cloth for eyeglass lenses. Do not use alcohol or other corrosive substances for cleaning or allow them to get inside.

- Do not expose your device or its accessories to open flames or lit tobacco products.
- Do not expose your device or its accessories to liquid, moisture or high humidity.
- Do not drop, puncture, crush, throw or try to bend your device or its accessories.
- Do not paint your device or its accessories.
- Do not attempt to disassemble your device or its accessories. Only authorized personnel can do so.
- Do not attempt to disassemble the screen. You may get cut by broken glass.

- When the decoration ring breaks, replace with a new one before using the watch to avoid cutting yourself.
- Do not wrap your device, charging cable or adapter in quilts or other packages during use or charging.
 Poor ventilation may cause heat build-up and damage internal components or cause fire.
- Do not wear or play with the device while it is being charged.
- Do not use conductive foreign objects (such as metal plates, pencils, etc) to contact with the charging port or connectors.
- Do not expose or use your device or its accessories in an environment with or that can reach extreme temperatures.

- Do not place your device inside or near heating equipments or high pressure containers, such as water heaters, microwave ovens, or hot cooking utensils. Otherwise, your device may be damaged.
- Please check local regulations for disposal of electronic products.
 Small Children

Do not leave your device and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the device.

Your device contains small parts that may cause an injury or may become detached and create a choking hazard. Do not allow children to removed or install the decoration ring by themselves. They may break the ring and cut themselves or others.

Never allow children to assemble or remove the watch bands by themselves. They may scratch themselves or eat the screws by accident.

Children should use the device under adult supervision.

Watch bands may cause infant suffocation. Put the device out of your baby's reach.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media to be close to your device for a long time.

Seizures/Blackouts

The device can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to flashing lights or light patterns such as when playing games or watching video. If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician.

Emergency Calls

This device operates using radio signals, which cannot guarantee connection in all conditions.

Loud Noise

This device is capable of producing loud noises, which may damage your hearing. Turn down the volume if necessary. Users who have heart disease should pay attention to the vibration and volume settings.

Sensitive Skin

Some people may have allergic reaction when their skin is exposed to wearable items for a long time. This may be due to allergies. environmental factors, exposure to irritants (such as soap or sweat) or other factors. If you have allergies, you may feel uncomfortable when using a wearable device. If you do have skin allergy, please pay special attention. Do not wear the device too tight. Let the skin breathe by removing the device regularly. Keep the device clean and drv will reduce the likelihood of skin discomfort. If the skin shows redness, swelling, itching or other allergic symptoms around the area where you wear the device.

Please remove the device and consult a physician.

Even when the symptoms alleviate, they may be induced again if you continue to wear the device.

Device Cleaning

Keep your watch clean and dry. After exercising or sweating, clean and dry the watch, the bands and your skin. If exposed to water, dry the device thoroughly.

Clean the watch when following situations appear: contact with dirt or other damaging substances (such as dust or sand, cosmetics, ink, soap, cleaning agent, acid or acid food), contact with non-water liquid and liquid that may cause skin allergy (such as sweat, brine, soap water, perfume, pesticide spray, lotion, sunscreen, oil, hair dyer, or solvent). Watch and bands color may vary, or fade over time. Clean the watch with a soft non-fleece cloth. If necessary, moisten the cloth with clean water.

Device Heating

Your device may become warm during charging and during normal use. During use in high temperature environments, such as inside a car or under direct sunshine for a long time, the watch may start to control its temperature to prevent users from being burned. You may encounter the following situations: charging slows down or stops, the screen turns dark, temperature warning appears on the screen, data transmission is suspended or delayed, or phone call may be turned off.

If your arm feels uncomfortable, please take off the watch temporarily.

The watch may become warm during FOTA upgrade. Please take off the watch during the upgrade.

The surface temperature of the watch complies with standards and limits on temperature rise.

However, even within these limits,

prolonged contact with a warm surface may cause discomfort or injury.

If the temperature of the watch makes you uncomfortable, take it off.

Electrical Safety

Accessories

Use only approved accessories. Do not connect with incompatible products or accessories. Never puncture the surface of the device with sharp objects.

Faulty and Damaged Products

Do not attempt to disassemble the device or its accessories.

Only qualified personnel can service or repair the device or its accessories. If your device (or its accessories) has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

Radio Frequency Interference

General Statement on Interference

Care must be taken when using the device in close proximity to personal medical devices, TVs, radios, and personal computers.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 20 cm be maintained between a mobile device and a pacemaker to avoid potential interference with the pacemaker.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby. The level of interference will depend on the type of hearing device and the distance from the interference source. Increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Devices

Please consult your doctor and the device manufacturer to determine if operation of your watch may interfere with the operation of your medical device.

Hospitals

Turn off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Turn off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices onboard the aircraft. If your device offers a 'flight mode', this must be enabled prior to boarding an aircraft.

Interference in Cars

Please note that because of possible interference with electronic equipment, some vehicle manufacturers forbid the use of mobile devices in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments Gas Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your watch or other radio equipment. Do not use or charge the device.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile device when in a blasting area or in areas posted power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.

Manufacturer's Warranty

ZTE offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship for a period that expires one year from the date of sale of the Product to you, provided that you are the original end user purchaser of the Product and provided that your purchase was made from a supplier authorized by the Seller. Transfer or resale of a Product will automatically terminate warranty coverage with respect to that Product. This limited warranty is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Product. This limited warranty is applicable only to end users in the United States.

- This product is warranted for 12 (twelve) months from date of purchase.
- The product will be repaired or replaced free of charge by local Authorized Service Centers, if, at their sole discretion, it is found to be faulty within the warranty period.
- This warranty only applies to products sold and distributed within approved countries by ZTE and its authorized distributors and/or retail outlets.
- This warranty only applies if the product has been used in accordance with the manufacturer's instructions under normal use and with reasonable care.
- 5. What this warranty does not cover:
 - Defects or damages resulting from the misuse of this product.

b) Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture, dampness or corrosive environments, unauthorized modifications. unauthorized repair, neglect, rough handling, abuse, accident, alteration, improper installation. incorrect voltage application, food or liquid spoilage, acts of God.

- c) Normal wear and tear.
- If the Product has been opened, modified or repaired by anyone other than a warranty service center or if it is repaired using unauthorized spare parts.

e) If the serial number or mobile accessory date code has been removed, erased, defaced, altered or are illegible in any way subject to sole judgment of ZTE.

LIMITED WARRANTY

TO THE EXTENT PERMITTED BY APPLICABLE LAW, THIS LIMITED WARRANTY IS YOUR SOLE AND EXCLUSIVE REMEDY AGAINST ZTE AND ZTE'S SOLE AND EXCLUSIVE LIABILITY IN RESPECT OF DEFECTS IN PRODUCT. HOWEVER, THIS LIMITED WARRANTY SHALL NOT EXCLUDE NOR LIMIT ANY OF YOUR LEGAL (STATUTORY) RIGHTS UNDER THE APPLICABLE NATIONAL LAWS.

TO THE EXTENT PERMITTED BY APPLICABLE LAW ZTE DOES NOT

ASSUME ANY LIABILITY FOR LOSS OF OR DAMAGE TO OR CORRUPTION OF DATA, FOR ANY LOSS OF PROFIT. LOSS OF USE OF PRODUCTS OR FUNCTIONALITY, LOSS OF BUSINESS, LOSS OF REVENUES OR LOSS OF ANTICIPATED PROFIT. INCREASED COSTS OR EXPENSES OR FOR ANY INDIRECT, OR SPECIAL OR CONSEQUENTIAL LOSS OR DAMAGE. TO THE EXTENT PERMITTED BY APPLICABLE LAW. ZTE'S LIABILITY SHALL BE LIMITED TO THE PURCHASE VALUE OF THE PRODUCT THE ABOVE LIMITATIONS SHALL NOT APPLY TO DEATH OR PERSONAL INJURY CAUSED BY DEFECT OF PRODUCT IN MATERIAL, DESIGN AND WORKMANSHIP.

LEGAL INFORMATION

Copyright © 2017 ZTE

CORPORATION.

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

Notice

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

We offer self-service for our smart terminal device users.

Please visit the ZTE official website (at www.ztedevice.com) for more information on self-service and

supported product models. Information on the website takes precedence.

Disclaimer

ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software.

Images and screenshots used in this guide may differ from the actual product. Content in this guide may differ from the actual product or software.

Trademarks

ZTE and the ZTE logos are trademarks of the ZTE Corporation.

The *Bluetooth*[®] trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license.

Qualcomm[®] Snapdragon[™] processors are products of Qualcomm Technologies, Inc. Wi-Fi[®] and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.

T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG.

Other trademarks and trade names are the property of their respective owners.

Version No.: R1.0

Edition Time : February, 2017



ZTE ZTE CORPORATION

NO. 55, HI-tech Road South, ShenZhen, P.R.China Postocde: 518057 http://www.ztedevice.com mobile@zte.com.cn Service Hotline: 1-877-817-1759

The information on the package is only for your reference. Images are for your reference only. Plasse check the product model before purchasing. ZTE reserves the rights to change specifications and parameters of the products without further rotics.

TCS534395.1